

Outhouse XL

Instructions & Care Manual

IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 x Flysheet (or outer)

2 x Poles

1 x Bag of Pegs

1 x Groundsheet

1 x Repair Kit

1 x Carrying Bag



We highly recommend that you insure your Outhouse against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the Outhouse or its contents because of misuse, incorrect pitching or extreme weather. (Full warranty details are at the back of this booklet).

IMPORTANT INFORMATION

- ⇒ Please do not leave for your holiday without fully erecting and checking you have all the contents for your awning. If you are missing anything please contact your retailer immediately before use.
- ⇒ Please also note that manmade fabrics are prone to condensation when the warm air and moisture inside the awning comes into contact with the colder outside of the awning fabric. This is a perfectly natural occurrence and should not be confused with leaking. Ensure all Vortex Vents are open whenever possible to help combat condensation.
- ⇒ Ideally erect your awning for some period before use - allowing it to weather. 'Weathering' can take a few uses of the awning before it is fully effective. Seam sealant can be used to solve any persistent weeps. This process is completely normal.
- ⇒ Make sure before erecting, that you site the awning on clear level ground with no sharp objects underneath, and that all the zips are fully closed. (We recommend laying a groundsheet down to keep the awning dry and clean).
- ⇒ We suggest conducting a trial run of your awning to familiarise yourself with the set up and use of the awning. If you have any issues relating to pitching your awning please contact your dealer for help before going on holiday.
- ⇒ Please note this awning is designed as a 'touring' awning and not for permanent pitch.
- ⇒ After use always dry and air the awning before packing away to prevent mildew or mould.
- ⇒ Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents as this will destroy the waterproofing on the fabrics.
- ⇒ DO NOT cook or smoke in this awning; although the outer fabric is flame retardant treated it will still melt.
- ⇒ In the event of damage; please contact your retailer. If you cannot get in touch with them use our contact form on our website www.outdoor-revolution.com and our customer service team will be happy to assist.

PLEASE READ THE FOLLOWING ERECTION INSTRUCTIONS CAREFULLY

TIP: Refer to the photograph to help when pitching your Outhouse

1. Spread the flysheet out on the ground in the space you want to pitch it.



2. Locate the bag of poles and erect the two individual poles.



3. Thread the two poles through the sleeves and insert the pins from the ring and pin in to the bottom of each pole.



4. Clip the black clips on to the four pole sections that aren't inside the sleeves.



5. Peg the Outhouse down by pegging the four corners out, pulling it taught but not over tensioning.



6. Stretch the groundsheet out and lay this inside the outhouse. Peg the groundsheet down.



7. Finally, peg out the guy lines on the outhouse.

OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the highest manufacturing standards. The best quality fabrics and components available are used for each specific item and rigorous checking of finished products is in place.

All finished products are:-

- Checked for, and are free of minor defects
- Are fit for the purpose/use that they are intended
- Are of a satisfactory quality

It is important that correct care is taken when opening the product, erecting, using and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for hints and tips on handling/erecting the product). A repair kit is included in the product to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warrant lasts for 12 months from the original date of purchase (please keep all receipts or copies of any relevant transaction to substantiate the purchase date). The warranty only covers workmanship and fabric/components. Any faults found within 6 months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you the purchaser, in line with current consumer legislation after the short term right to reject has ended.

Retailer will not refund a purchase if no fault is found. Product warranty must be registered **BEFORE** use via www.outdoor-revolution.com and as soon as possible from the date of purchase.

The manufactures warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.

THE WARRANTY (CONTINUED)...

- Accidental damage caused by but not exclusive to, human, animal or weather.
- Flaws in the fabric caused by excessive use.
- Water ingress through fabric as a result of UV degradation.
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- UV degradation.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.


Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues. **Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Please ensure the product is clean and dry and as close to its original condition a possible before sending back for checking.

**Wet or dirty products will not be accepted back for checking/warranty claims.

** It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed, our products are designed for durability and for ease of erection.



Outdoor Revolution Awnings are distributed by:

www.outdoor-revolution.com

Unit 1 Brick Park
Bretfield Court
Bretton Street Industrial Estate
Dewsbury
West Yorkshire
WF12 9BY



**OUTDOOR
REVOLUTION**
WWW.OUTDOOR-REVOLUTION.COM