Thank you for purchasing an Outdoor Revolution product. This product will give years of satisfactory service if basic instructions are followed. Our products are designed for durability, longevity and ease of erection.



WWW.OUTDOOR-REVOLUTION.COM

Unit 1 Brick Park Bretfield Court

Bretton Street Industrial Estate

DEWSBURY

WEST YORKSHIRE

WF12 9BY

In the interest of continuous development and improvements by Outdoor Revolution; some products or specifications may vary slightly from the photographs and information provided in this instruction manual. Dimensions and weights are approximate and intended as guidelines only.





O-zone 6.0XTR Safari Front Air Canopy Instructions & Care Manual





IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 x Flysheet (Or Outer)

1 x Oxygen Air Frame Tube

1 x Bag of Ground Pegs

1 x Carry Bag

Guylines



We highly recommend that you insure your canopy against storm damage, or accidental damage, as the warranty does not cover such eventualities. The manufacturer <u>IS NOT</u> liable for any damage caused to the canopy, or its contents, due to misuse, incorrect pitching or severe weather conditions; full warranty details are at the rear of this booklet.

THE GUARANTEE (CONTINUED)...

registered in accordance with the manufacturer's registration process.

OR reserves the right to appoint its own representative to inspect the awning/tent, tube or associated components, prior to any repair or replacement of part(s) covered.

Replacement INTELLIGENT FRAMES under the lifetime guarantee will be dispatched to any UK mainland address free of Charge. Shipping charges covering the cost to dispatch the INTELLIGENT FRAMES to destinations outside of the UK mainland will be applied and payable before being despatched. (**Please note this service may take over 3 days).

Covered components of the Lifetime Warranty

The Lifetime Warranty is valid only for the following components of the awning or tent::

The air tube containing the IF (Intelligent Frame) only

Maintenance repairs and general wear and tear are not covered by the Lifetime Guarantee.

1.3. Customer duties to retain warranty

Online Registration of product is required to validate the Lifetime Warranty; the warranty automatically ceases on re-sale of the product.

The recommended pressure is of 4PSI; as soon as air is heard releasing from the IF valve, inflation must cease.

The warranty does not cover deliberate defacement, human error, misuse or accidental damage; the Lifetime Warranty is a guarantee against manufacturing flaws, solely of the tube.

1.4. Data protection

The activation and validation of the Lifetime Warranty requires OR to maintain personal data of the owner. Blue Diamond Products Limited and Outdoor Revolution will not pass your data onto any third parties and we will not use your data for any marketing purposes without your consent.

LIFETIME GUARANTEE

This warranty provided by the manufacturer does not adversely affect the statutory rights of the purchaser against the seller and gives remedies in addition to those against the seller under the contract of sale. Claims by the purchaser, in particular for a defect on an Intelligent Frame (IF), against the selling Outdoor Revolution distributor remain unaffected by the warranty.

Outdoor Revolution (hereinafter called "OR"), a subsidiary of Blue Diamond Products Ltd group, and its successors in title, warrants for awnings, or tents using IF technology, of their manufacture:

12 months, without limitation, a warranty against all manufacturing defects of the entire product.

1. LIFETIME WARRANTY OF THE INTELLIGENT FRAME FOR THE FIRST REGISTERED OWNER

1.1. Duration of Warranty

OR undertakes that each new awning/tent supplied thereon by OR as original equipment will be free from defect in material or workmanship according to the state of the art under normal use and service for the Lifetime of the awning/tent. The warranty is valid for the first registered owner of the awning/tent, who bought the product at an OR Authorised Retailer.

The warranty starts on the date of first registration, THIS MUST BE WITHIN 14 DAYS OF PURCHASE.

1.2. Coverage of the Lifetime Warranty

The warranty applies to free of charge repair, or replacement of the IF tube by OR i.e. OR's obligations under this warranty being limited to repairing or replacing at its option any parts or Tube by either OR, or an OR Authorised Repairer. The repair or replacement of defective parts under this undertaking will be made by the Authorised Repairer to whom the awning is returned, free of charge to the customer.

For the parts fitted during a repair, until expiry of the warranty limitation according to Paragraph 1, the same warranty is given as for the awning, tent, frame or associated parts i.e. the warranty is not extended by the repair or replacement of parts even for the parts rectified or replaced. Replaced parts become the property of OR.

Lifetime Warranty cover is dependent upon confirmation that the awning/tent has been

IMPORTANT INFORMATION

- ♦ Please do not leave for your holiday without fully erecting and checking that you have all the listed contents for your canopy. If you are missing anything, then please contact your retailer immediately before use.
- Please note that man-made fabrics are prone to condensation, when the warm air and moisture within the canopy, comes into contact with the colder air on the outer material; this is a perfectly natural occurrence and should not be confused with leaking. Please ensure that any available ventilation points remain open, wherever possible, in order to help combat condensation.
- We suggest that you pitch your canopy for some period before use, enabling it to undergo the 'weathering' process. Weathering sometimes requires a few uses of the canopy, before it becomes fully effective. Seam sealant can be used to resolve any persistent weeps; this is a natural process. 'Weathering' is the process of allowing your canopy to become soaked, then completely dry, approximately two to three times to reinforce the waterproofing of the seams/stitching on the canvas.
- Please ensure that you site the canopy on clear/level ground before erecting, with no sharp objects beneath and zips fully closed. We suggest placing a groundsheet underneath the canopy to keep it dry/clean.
- We suggest conducting a trial run of your canopy to familiarise yourself with the
 assembly and usability of the model. Should you have any issues in relation to
 pitching your canopy; please contact your dealer for assistance before your holiday.
- Please note that this model is designed for short term usage and not long term pitch.
- Always properly dry/air the canopy after use, before packing away, to prevent mildew or mould from developing.
- Any dirt or stains can be removed by brushing, or gently washing, using warm water. DO NOT use detergents, as this will destroy the waterproofing of the materials.
- ♦ DO NOT cook or smoke inside this canopy, as despite the outer fabric being flame retardant; it will still melt.
- In the event of damage; please contact your retailer. If, for whatever reason, you are unable to contact them, then please email co.uk and our dedicated customer service team will be pleased to assist you.
- Please avoid using this canopy in temperatures below freezing, as this can result in cracking of the Oxygen Air Frame.
- Always store your canopy flat, never on the side of the bag, as this can cause damage to the Oxygen Air Frame tube; this should be stored in cool/dry areas where possible.

PLEASE READ THE FOLLOWING ERECTION INSTRUCTIONS CAREUFULLY

TIP: Refer to these photographs when erecting of your Ozone 6.0XTR Safari Front Canopy.



1. Spread the canvas out on the ground, with the longer zip laid near the front of your family tent.

2. Attach the canopy to the front of the family tent using the sewn in zip.







3. Locate the Dynamic Speed Valve and ensure the valve is **closed**, before attaching the pump; the valve is **closed** once the button has been pressed out. There is another valve at the opposite end of the tube; please ensure that this is also closed.

4. Begin to carefully inflate, whilst ensuring that none of the fabric has become caught anywhere.



- Damage caused by incorrect maintenance of the product.
- Flaws in the fabric caused by excessive use.
- Imperfections and pulls in mesh doors due to wear and tear.
- Water ingress through fabric as a result of accelerated UV degradation due to long term pitch .
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues:

Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Returning Products

Please ensure the product is clean and dry and as close to its original condition as possible before sending back for checking. Wet or dirty products will not be accepted back for checking/warranty claims.

It is important to note that the sales contract between yourself and the retailer that you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the very highest of manufacturing standards, using the best quality fabrics or components available for each specific model. Rigorous quality control of finished products is in place.

- All manufactured products are:
- Quality controlled to be free from minor defects.
- Fit for the purpose that they are intended for.
- Manufactured to a satisfactory quality.

It is important that correct care is taken when opening, erecting, using, and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for handling/erection tips). A repair kit is included with each of our products to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warranty lasts for twelve months from the original date of purchase; please keep all receipts or copies of any relevant transaction to substantiate the purchase date. This warranty only covers the workmanship, fabric and components. Any faults found within six months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you, the purchaser, in line with current consumer legislation, after the short term right to reject has concluded. **Please note that this warranty requires registration on our website.**

Retailer will not refund a purchase if no fault is found.

The manufacturers warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.
- Accelerated UV damage caused by excessive, long term sun exposure.
- Accidental damage caused by but not exclusive to, human, animal or weather.

5. Inflate the Oxygen Air Frame until you can give it a 'good squeeze', allowing space inside for air to expand, should there be an increase in the ambient temperature. Replace the cap and cover it with the Velcro sleeve for a neater external aesthetic. Please note that the pressure relief valve will expel any excess air above 6PSI.





6. Secure any available adjustable pegging straps, using the ground pegs to tension it as much as you desire; please be careful not to overtension the material whilst doing this.

7. Please peg down any available guylines, storm straps or pegging points for maximum stability during adverse weather conditions.



LIFETIME GUARANTEE

The Oxygen Air Frame tubes incorporate an exclusive **LIFETIME GUARANTEE** against any manufacturing faults.

You must register for the **LIFETIME GUARANTEE** on the Outdoor Revolution website within **fourteen days** of the purchase to **validate** your warranty.

Terms and Conditions apply. Read the full T & C on our website!

WARNING: Never unzip the zips on the protective sleeves whilst the Oxygen Air Frame Tubes are inflated. This will result in the tube bursting/ballooning out of the sleeve, causing damage to the tube and sleeve; this is NOT covered under the warranty!

PACKING AWAY YOUR CANOPY

- ♦ Zip up any windows/doors before deflating.
- Unpeg any guylines, storm straps and most of the pegs around the canopy, leaving the four corners pegged out.
- Open the Dynamic Speed Valve, before pushing in the quick release button;
 please leave this button pressed in.
- Unpeg each of the four corners.
- Please unzip the canopy from your family tent before packing away.



Allow the canopy to collapse on itself, before compressing as much air out of the tubes and canvas as possible.

Fold the canopy on itself vertically to form a rectangular shape.





Fold the canopy on itself to create a streamlined 'sausage' shape. Measure the width of the canopy against the bag to ensure that it will fit inside. Start rolling the model, pushing out any air as you roll.

Rotate the rolled canopy onto the carry bag, pull the sides up around it, then zip up the bag.



TROUBLE SHOOTING

| PROBLEM | REASON | <u>SOLUTION</u> |
|--|---|--|
| The Oxygen Air Frame is deflating after removing the pump. | The Dynamic Speed Valve button hasn't been pressed back out. | Press the quick release button back out to close the valve. |
| The canopy is leaking water. | This canvas requires 'weathering', before it fully seals itself, therefore you may experience some weeping. This could also be condensation; an inevitable occurrence. | Allow the canopy to get completely soaked, then fully dried, two to three times. Open any ventilation points to optimise air circulation and reduce condensation. |
| Bowing and twisting of the tubes. | The tubes may twist when inside the sleeves, especially when packing away, so next time the tube bows | Unzip the sleeve, whilst the tube is deflated, then reposition the tube. |

IN THE EVENT OF A PUNCTURE

If you locate a small puncture in your 'Oxygen Air Frame Tube', you can easily repair it, using the standard puncture repair kit, which should be packed with your model.

- ♦ To remove the air frame tube; deflate the tube, unzip the two protective sleeve covers and pull it out. Please do not unzip the sleeves whilst the tube is inflated.
- Scrutinise the tube for any punctures and repair the puncture on the oxygen air frame bladder using the inclusive adhesive repair patch.
- Place the Oxygen Air Frame Tube back into the sleeve, in the correct position, with the valves in their respective sockets, ensuring that the bladder is not twisted.
- ♦ Zip each of the two sleeves back up.
- ♦ Begin to inflate the Oxygen Air Frame Tube again, ensuring that the puncture repair has been successful.
- If this process does not work, then you may need to purchase a new bladder.
- **Spare Oxygen Air Frame bladders can be purchased to replace damaged ones. Visit the spares section at: www.outdoor-revolution.com or contact us on 01924 455 313.
 - **Awnings & Tents Will Not Be Replaced Due to Damaged Bladders**