Thank you for purchasing an Outdoor Revolution product.
This product will give years of satisfactory service if basic instructions are followed. Our products are designed for durability and ease of erection.



WWW.OUTDOOR-REVOLUTION.COM

Unit 1 Brick Park
Bretfield Court

Bretton Street Industrial Estate

DEWSBURY

WEST YORKSHIRE

WF12 9BY

In the interest of continuous development and improvements by Outdoor Revolution; some products or specifications may vary slightly from the photographs and information provided in this instruction manual. Dimensions and weights are approximate and intended as a guidelines only.





PRONTO WINDBREAK INSTRUCTIONS & CARE MANUAL





IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 x 480HDE DRS FLYSHEET (OR OUTER)

1 x Upright Fibreglass Pop Up System (16 Poles)

5 x Fibreglass Poles

1 x Steel Ground Peg Bag

1 x Carry Bag

6MM KADER PIPING

GUYLINES



We highly recommend that you insure your windbreak against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer <u>IS NOT</u> liable for any damage caused to the windbreak or its contents due to misuse, incorrect pitching or extreme weather (full warranty details on rear of booklet).

NOTES

8

- Damage caused by incorrect maintenance of the product.
- Flaws in the fabric caused by excessive use.
- Imperfections and pulls in mesh doors due to wear and tear.
- Water ingress through fabric as a result of accelerated UV degradation due to long term pitch .
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues:

Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Returning Products

Please ensure the product is clean and dry and as close to its original condition as possible before sending back for checking. Wet or dirty products will not be accepted back for checking/warranty claims.

It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

IMPORTANT INFORMATION

- ♦ Please do not leave for your holiday without fully erecting and checking you have all the contents for your windbreak. If you are missing anything, please contact your retailer immediately before use.
- Please also note that man-made fabrics are prone to condensation when the warm air and moisture inside the windbreak comes into contact with the colder air on the outside of the windbreak fabric. This is a perfectly natural occurrence and should not be confused with leaking. Please ensure that all ventilation points are open whenever possible to help combat condensation.
- Ideally, erect your windbreak before use, in order to allow it to undergo the 'weathering' process. 'Weathering' can require a few uses of the gazebo before it becomes fully effective. Seam sealant can be used to solve any persistent weeps; this process is completely natural. 'Weathering' is the process of enabling your windbreak to get soaked, then completely dry, approximately two to three times, in order to reinforce the waterproofing of the seams/stitching.
- Please ensure that before erecting, you site the windbreak on clear, level ground, with no sharp objects beneath it.
- We suggest conducting a trial run of your windbreak to familiarise yourself with the assembly and use of the product. If you encounter any issues in relation to pitching your windbreak, please contact your dealer for assistance before going on holiday.
- Please note this windbreak is designed for touring use and not long term pitch.
- Always properly dry or air the windbreak after use, before packing away, in order to prevent mildew or mould build up.
- Any dirt/stains can be removed by brushing, or gently washing, with warm water. DO
 NOT use detergents, as this will destroy the waterproofing of the fabrics.
- ♦ DO NOT cook or smoke within close proximity of this windbreak; despite the outer fabric is being flame retardant, it may still melt.
- In the event of damage; please contact your retailer. If, for whatever reason, you are unable to contact them, then please email: <u>cs@blue-diamond-products.co.uk</u> and our customer service team will be happy to assist you!
- ♦ Please avoid using this windbreak in temperatures below freezing, as this can result in a detrimental effect on the windbreak frame.
- Always store your gazebo flat, never on the side of the bag, as this can cause damage to the fibreglass pop up system; this bag should be stored in a cool/dry area.

OPTIONAL ACCESSORIES

None.

12 MONTH MANUFACTURERS WARRANTY

On The Workmanship/Canvas.

Visit www.outdoor-revolution.com for more information.

OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the very highest of manufacturing standards, using the best quality fabrics or components available for each specific model. Rigorous quality control of finished products is in place.

All manufactured products are:

- Quality controlled to be free from minor defects.
- Fit for the purpose that they are intended for.
- Manufactured to a satisfactory quality.

It is important that correct care is taken when opening, erecting, using, and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for handling/erection tips). A repair kit is included with each of our products to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warranty lasts for twelve months from the original date of purchase; please keep all receipts or copies of any relevant transaction to substantiate the purchase date. This warranty only covers the workmanship, fabric and components. Any faults found within six months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you, the purchaser, in line with current consumer legislation, after the short term right to reject has concluded. Please note that this warranty requires registration on our website.

Retailer will not refund a purchase if no fault is found.

The manufacturers warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.
- Accelerated UV damage caused by excessive, long term sun exposure.
- Accidental damage caused by but not exclusive to, human, animal or weather.

PACKING AWAY YOUR WINDBREAK

- Please zip up all windows/doors before disassembly.
- Unpeg all pegs surrounding the windbreak, leaving each corner pegged out.
- Extract the pegs from each corner.

Fold each windbreak panel down to reverse the effects of the pop up system.



Allow the windbreak to collapse on itself after pushing the fibreglass pop up system back into its original configuration.

Fold the windbreak on itself vertically to form a rectangular shape.



Fold the windbreak on itself to create a streamlined sausage shape. Measure the width of the windbreak sausage against the bag to ensure it will fit. Begin rolling the windbreak, pushing any air out as you roll.

Roll the windbreak into the designated storage bag and pull each side up around it. Compress this as much as you wish for ease of transportation.

5



PLEASE READ THE INSTRUCTIONS CAREFULLY

<u>TIP:</u> Refer to the photographs to help when pitching your 'Pronto Windbreak'.



1. Spread the windbreak frame out on the ground as flat as possible.

2. Use the metal loop to pull out the fibreglass pop up system on each panel. This should give the windbreak freestanding capabilities. You could thread a guyline through this metal loop for extra leverage to simplify this process. Please note that this is easier with two people, with one person holding the panel, whilst the other pops out the frame.







3. Place the five windbreak poles into the corresponding sleeves on the windbreak frame.



4. Work your way around the windbreak, pummelling pegs into any securing loops, as well as any all as guylines, for additional stability during adverse weather conditions.



